



**NOTES:**

1. HOSE BIB SHALL ACCOMMODATE STANDARD 3/4" GARDEN HOSE.
2. A BACKFLOW PREVENTER WITH ENCLOSURE SHALL BE INCLUDED ON ALL TEMPORARY FAUCETS AS REQUIRED BY THE CROSS CONNECTION ORC.
3. A VACUUM BREAKER IS REQUIRED ON HOSE BIB.
4. A GATE OR BALL VALVE SHALL BE PROVIDED BEHIND THE CITY'S METER, IN A SEPARATE VALVE OR METER BOX.
5. THE TEMPORARY FAUCET MUST BE REMOVED BEFORE OCCUPATION OF THE STRUCTURE. NO FINAL APPROVAL CAN BE GIVEN UNTIL THE TEMPORARY FAUCET IS REMOVED.

NOT TO SCALE

## TEMPORARY FAUCET